
CEREC[®] Connect


Reference Guide



GLIDEWELL LABORATORIES

800-887-3580 • www.glidewelldental.com


How to Scan CEREC® Cases Using V3.83 Software – Buccal Scan –




Step 1: Scan the preparation (extending to include the entire quadrant). The preparation must have clear margins.




Step 2: Scan the antagonist (opposing teeth quadrant).




Step 3: Take the buccal scan. You may also choose bite registration.




Step 4: You will see an image of the virtual model for correlation.




Step 5: Follow the instructions on the bottom left corner of the screen to articulate the virtual model.




Step 6: Move buccal image towards preparation.



Step 7: Move opposing teeth towards prep and buccal scan.




Step 8: Verify 3-D model. On view window, click “Buccal” and “Antagonist” before marking margins. Enter margin line(s). Follow instructions on bottom left corner of screen to mark margins for single or multiple tooth numbers.




Step 9: Click “Connect” to send case to lab. Enter username and password.


How to Scan Full Arch CEREC® Cases Using V3.83 Software




Step 1: Select the "Preparation" icon on the left side of screen.



Step 2: Scan the first quadrant, starting from the posterior moving to the midline.



Step 3: Next, click on the middle icon on the upper left hand of preparation window. Begin scanning the counter quadrant starting from the posterior, past the midline, to allow images to overlap.




Step 4: Click on the third icon to virtually stitch both quadrants together to create a full-arch image.


How to Send Your CEREC® Files to Glidewell Laboratories




Step 1: Fill out digital Rx: Enter Patient Name, Restoration Type, Material, Stump Shade, Final Shade and Tooth Number(s). Click "Next Step."




Step 2: Desired lab: Enter "Glidewell Laboratories" and then choose "Return Date/Time." Select "Next Step."



Step 3: Additional notes: Fill out additional instructions. When finished, hit "Upload" (if any). Click "Next Step."



Step 4: The case will begin to upload.



Step 5: You will receive confirmation that your digital impression has been added to the cart. Click "Next Step."



Step 6: Verify your order details. Enter username and password. Click "Submit."



Step 7: Finally, you will receive a message that your order has been successfully submitted.